



West Bay Sanitary District Code of Safe Practice

FOR IMMEDIATE RELEASE
Initial: June 01, 2012

Questions or comments regarding this
Code of Safe Practice should be directed
to the Regulatory Compliance Coordinator.

Asphalt Paver

- Pre-inspect equipment including rental equipment.
- Review and understand the manufacturer's operator's manual for this equipment.
- Do not load until you have received proper training.
- Pre-operate before using (i.e., chains, cables, tires, and batteries).
- Always use haul truck suited for safe towing.
- Use of another person for hook-up is advisable.
- Driver is responsible that proper hook-up is made and all items are secure for towing.
- Do not load paver onto trailer until trailer is hooked to truck.
- Check brake adjustment.
- Do not use "break-away" system as a parking brake
- Secure "Raising Stand" before towing.
- One person only operates loading controls.
- Secure paver on trailer before towing.
- Tow only at a safe speed allowing for road conditions, 45 mph (72 kilometers per hour maximum).
- Always wear proper apparel, especially gloves, when handling cables.
- Have worn parts replaced immediately (i.e., frayed cables, worn tires, broken chains, etc.).
- Do not place fingers near trailer tilt latch until the towing vehicle has stopped.

PERSONAL PROTECTIVE EQUIPMENT

Protection Area	PPE Required
Eye	Safety glasses or goggles meeting the ANSI Z87.1 Standard.
Face	
Hand	Work gloves.
Head	Hardhat.
Foot	Leather steel toe safety shoes or boots.
Body	
Respiratory	
Hearing	Wear earplugs or earmuffs as necessary.