



West Bay Sanitary District Code of Safe Practice

FOR IMMEDIATE RELEASE
Initial: June 01, 2012

Questions or comments regarding this
Code of Safe Practice should be directed
to the Regulatory Compliance Coordinator.

Flashing Arrow Board, Trailer Mounted

- Pre-inspect equipment including rental equipment.
- Review and understand the manufacturer's operator's manual for this equipment.
- Check for oil residue build-up in engine compartment. Keep clean.
- Check frame for cracks and loose bolts.
- Use jacks to stabilize operating flashing arrow board.
- Make sure locking pins are used and secure when jacks are down or up.
- When towing, jacks shall be pinned in the up position.
- Check for frayed electrical wires and cables.
- Check for proper hook-up of trailer to vehicle and use safety chain. Check before leaving yard.
- Release hand brake when towing and secure when parked.
- Check that arrow board is down when towing and secure with hold-down fastener.
- Keep fingers out of pinch points when raising and lowering flashing arrow sign and when connecting or disconnecting from towing vehicle's hitch.

PERSONAL PROTECTIVE EQUIPMENT

Protection Area	PPE Required
Eye	Safety glasses or goggles meeting the ANSI Z87.1 Standard.
Face	
Hand	Work gloves.
Head	Hardhat.
Foot	Leather steel toe safety shoes or boots.
Body	
Respiratory	
Hearing	Wear earplugs or earmuffs as necessary.