



West Bay Sanitary District Code of Safe Practice

FOR IMMEDIATE RELEASE
Initial: June 01, 2012

Questions or comments regarding this
Code of Safe Practice should be directed
to the Regulatory Compliance Coordinator

Mixer, Concrete

- Pre-inspect equipment including rental equipment.
- Review and understand the manufacturer's operator's manual for this equipment.
- Keep clear of pinch points.
- Use proper lifting procedures.
- Keep mixer and tools clean.
- Ensure that chutes are properly placed before dumping.
- Secure mixer and attachments before moving to new locations.
- Do not use frayed or worn power cords on electric mixers.
- Allow ample space for each employee to work safely.
- Never reach into drum while mixer is running.

PERSONAL PROTECTIVE EQUIPMENT

Protection Area	PPE Required
Eye	Safety glasses or goggles meeting the ANSI Z87.1 Standard.
Face	
Hand	Work gloves.
Head	Hardhat when appropriate.
Foot	Leather steel toe safety shoes or boots.
Body	
Respiratory	N95 dust mask when pouring dry concrete like Portland Cement.
Hearing	Wear earplugs or earmuffs as necessary.