



West Bay Sanitary District Code of Safe Practice

FOR IMMEDIATE RELEASE
Initial date: June 01, 2012

Questions or comments regarding this
Code of Safe Practice should be directed
to the Regulatory Compliance Coordinator.

Sweeper, Street

- Pre-inspect equipment including rental equipment.
- Review and understand the manufacturer's operator's manual for this equipment.
- Never leave the machine unattended with the engine running.
- Stop elevators and rear broom whenever repairing, adjusting, or removing obstructions.
- While driving, always scan the entire area for possible hazardous situations.
- When backing up, use your mirrors or get out and check if you are in doubt.
- Keep cab clean.
- Use safety stand when working under raised hopper.
- Drive carefully when deadheading, especially when loaded.
- Take extra caution when changing or adjusting gutter brooms, to avoid injuring self with steel bristle.
- Use hand and footholds when climbing onto and off sweeper or hopper.
- Don't attempt to sweep an unidentified substance.
- All repairs or adjustments should be made away from the traveled way.
- Do not load hopper beyond marked capacity.
- Use water to control dust.

PERSONAL PROTECTIVE EQUIPMENT

| Protection Area | PPE Required |
|-----------------|--|
| Eye | Safety glasses or goggles meeting the ANSI Z87.1 Standard. |
| Face | |
| Hand | Work gloves. |
| Head | Hardhat. |
| Foot | Leather steel toe safety shoes or boots. |

| | |
|-------------|---|
| Body | |
| Respiratory | N95 dust mask when appropriate. |
| Hearing | Wear earplugs or earmuffs when appropriate. |