



# West Bay Sanitary District Code of Safe Practice

FOR IMMEDIATE RELEASE  
Initial: June 01, 2012

Questions or comments regarding this  
Code of Safe Practice should be directed  
to the Regulatory Compliance Coordinator.

## Sweeper, Tow

- Review safe work practices for applicable equipment (including rental equipment) and perform pre-operational checks.
- Review and understand the manufacturer's operator's manual for this equipment.
- Check frame for cracks and loose bolts.
- If visual obstruction, due to sweeping, causes potential traffic hazards, use traffic controls.
- Check for proper hook up of sweeper to towing vehicle and use safety chain. Check chain before leaving yard.
- Operator shall be cautious of persons on foot during sweeping operations.
- Keep hands and feet clear when adjusting sweeper angle.
- While driving, always scan the entire area for possible hazardous situations.
- When dead heading make sure broom is raised and locked in place.
- Use water to control dust.
- Protect towing vehicle from rock damage.

### PERSONAL PROTECTIVE EQUIPMENT

Protection Area	PPE Required
Eye	Safety glasses or goggles meeting the ANSI Z87.1 Standard.
Face	
Hand	Work gloves.
Head	Hardhat.
Foot	Leather steel toe safety shoes or boots.
Body	
Respiratory	
Hearing	Wear earplugs or earmuffs as necessary.